

NEXTChem Process Analyzers, Inc.

On-Line Hydrosulfite

Industry: Textile

Sample Filtration is eliminated, in samples with high solids. For samples requiring dilution ≤ 2 mm particles can easily be handled. For non-dilution samples ≤ 6 mm particles pose no problem. No other system can match this rugged design.


NEXTChem Analyzers can provide accuracy only matched by the most precise laboratory equipment. Our reagent precision pumps deliver titrants with ± 0.001 mL reproducibility. Potentiometric analyses are utilized thus eliminating errors caused by electrode drift.



Analysis of Hydrosulfite

Hydrosulfite is determined by a redox titration. The inflection point of the analysis is used to determine with an ORP Electrode.

Reactions:



Reagents:

5 M Sodium Hydroxide, 0.25 N Potassium Ferricyanide, 3% Sodium Hypochlorite (Cleaner)

Sensor:

ORP Electrode 120 mm

Detection Limits / Interferences:

Dilution: 336,000 – 67 ppm

Non-Dilution: 640 – 0 ppm (lower detection limit 3 ppm)

Interferences: Other Redox Reagents

nextchem@nextchem-analyzers.com
1900 North Austin Ave., Suite 101 Chicago, IL 60639 USA
Office Phone +773-637-NEXT(6398) Office Fax +773-637-7260