

NEXTChem Process Analyzers, Inc.

On-Line Sulfite

Industry: Wastewater, Pulp and Paper, and Textile

Sample Filtration is eliminated, in samples with high solids. For samples requiring dilution ≤ 2 mm particles can easily be handled. For non-dilution samples ≤ 6 mm particles pose no problem. No other system can match this rugged design.



NEXTChem Analyzers can provide accuracy only matched by the most precise laboratory equipment. Our reagent precision pumps deliver titrants with ± 0.001 mL reproducibility. Potentiometric analyses are utilized thus eliminating errors caused by electrode drift.



Analysis of Sulfite

Sulfite is determined by an iodimetric titration. The inflection point of the analysis is used to determine with an ORP Electrode.

Reactions:



Reagents:

6 N Sulfuric Acid, 0.00625 M Potassium Iodate – Potassium Iodide

Sensor:

ORP Electrode 120 mm

Detection Limits / Interferences:

Dilution: 280,000 – 56 ppm

Non-Dilution: 533 – 0 ppm (lower detection limit 1 ppm)

Interferences: Other Redox Agents

nextchem@nextchem-analyzers.com
1900 North Austin Ave., Suite 101 Chicago, IL 60639 USA
Office Phone +773-637-NEXT(6398) Office Fax +773-637-7260